
TIDES MARINE

RPB Type E/F Installation Overview

The following is a description of the installation procedures associated with the RPB Type-E and RPB Type-F. Installation instructions are included with each unit and should be followed closely.

Type E

- 1. Prepare the rudder tube for bonding by wiping the inside clean of any dust or construction debris.
- 2. Using a medium bodied epoxy or Chockfast®, coat the outside of the bearing unit that will be pressed into the tube.
- 3. Lay a bead of marine sealant (such as Life-caulk™ or 3-M™ 101) under the flange.
- 4. Insert the unit into the tube.
- 5. Temporary support may be required to keep the unit in position. Install rudder or dummy shaft to insure good bearing alignment until cured.



NOTE: Before installing the rudder, insert the red installation hat into the lip seal. When rudÂder is in place, remove, invert and replace it on top of the Type-E/F unit to keep debris off the lip seal during use.

Type F

- 1. Prepare the rudder tube for bonding by wiping the inside clean of any dust or construction debris.
- 2. Using a medium bodied epoxy or Chockfast®, coat the outside of the bearing unit that will be pressed into the tube.
- 3. Insert the unit into the tube.
- 4. Temporary support (or blocking) may be required to keep the unit in position. Install rudder or dummy shaft to insure good bearing alignment until cured.

